

Designing ComfoPost

Tackling the issue of overheating requires an integrated solution, incorporating a suite of innovative products that each play their part in ensuring that indoor air quality and comfort levels are delivered during the warmer summer months, whilst also complementing heating requirements during the winter. In Passive House and Net Zero energy properties, these integrated products are likely to provide the sole source of heating.

Considering the expected increase in external temperatures predicted across the globe, being able to deliver forward thinking solutions can help mitigate the issue of overheating.



What is ComfoPost

The Zehnder ComfoPost is a range of air to water exchangers for use with ComfoWell air distribution connections. The ComfoPost helps to reduce the supply air temperature of the ComfoAir MVHR unit in the summer months and if required increase it in the winter months. Chilled water is fed into the ComfoPost during the summer months typically by a chiller or reversible heat pump to help reduce the supply air to all habitable rooms in the property resulting in comfortable supply air during warmer periods. In the winter warm water can be supplied to it to compliment any heating system, especially when using district heating to assist in reducing the return water flow temperature thus increasing efficiency.

The ComfoWell air distribution connections to the ComfoPost allows for ducting selection flexibility, offering a range of rigid circular ductwork or Zehnder ComfoTube semi-rigid ductwork to be attached. The ComfoPost units are also suitable for a wide range of airflows up to 166l/s (600m³hr). The units are made of steel with aluminium and copper pipe forming the heating and cooling coils and are maintenance free.

The ComfoPost can be controlled by the heating/cooling system controls and thermostats. Multiple ComfoPost units could also be used in the same property to enable zonal control.

The ComfoAir Q range of MVHR units can be used with the ComfoPost. These MVHR units are ideal for use with the ComfoPost due to the automatic cold recovery function when the internal temperature is lower than the external temperature. The ComfoAir Q350 has been the first unit to be independently certified by the Passivhaus Institute for its cold recovery efficiency of 87%. The ComfoAir Q range also have a unique modulating summer bypass. If the external temperature is lower than that of the internal temperature then it will activate to bring the cooler air into the property without the need for activating the ComfoPost. This can activate down to much lower temperatures than a standard summer bypass whilst avoiding hitting the dew point due to it being able to partially recover some of the heat. The ComfoAir Q also has 3 temperature profiles which react to the average external temperature. This means during spikes in external temperature the unit is more inclined to react to these sudden changes by opening the bypass or activating the ComfoPost accordingly.

The ComfoConnect KNX C or LAN C enable the end user to control and monitor the unit using the KNX building automation infrastructure or the ComfoControl free app (available on iOS and Android). These can be used to enable remote activation and support via the ComfoControl app.

The ComfoPost cannot be compared to air conditioning since air conditioning recirculates the stale cooled air, whilst the ComfoPost delivers fresh filtered air. This helps to meet ADF ventilation rates whilst having the added benefit of air temperation.



Design out overheating

The ComfoPost range can help to temper the supply air. However if the gains exceed the cooling capacity of the unit then the property will still overheat. Things to consider to combat overheating would be as follows:

- Improve thermal mass
- Options to cool thermal mass such as false ceiling or hollow core concrete flooring
- Reduce the size of windows and avoid too much south-facing glazing
- Solar shading through overhangs or external shutters
- Window glass type such as reflective, photochromic, thermochromic or electrochromic
- Insulate hot water pipes and tanks
- Reduce electrical appliances
- Use higher efficiency appliances that emit lower heat levels such as LED lighting
- Openable windows for purge ventilation without a security risk

Thermal modelling

It's important that thermal modelling is carried out to ensure the appropriate ComfoPost is selected and that it is sufficient to meet the cooling demands of the property. Thermal modelling is entirely reliant on the model inputs; we recommend modelling to the new TM59 guidance which draws from TM52 and CIBSE Guide A. Modelling should be based on the unit running at a minimum of 1 ach per habitable room or the minimum air flow published in the relevant ComfoPost Performance Data table, whichever is higher. The output will vary dependent on the conditions and water flow rate/temperature, the Performance Data table should be used as a guide for the units cooling/ heating capacity.

When modelling the property it's important that any solar shading requiring user intervention, such as blinds, is modelled with and without them. Window opening modelling should also include any restrictions and take into account noise, security and air quality issues which would reduce the opening area. The windows should also only be modelled as open when rooms are scheduled to be occupied unless security isn't an issue.





Additional notes

All equipment should be installed by a competent person; poor or incorrect installation could result in the unit not achieving its desired cooling capacity. The ISO ePM1 >55% (F7) filters within the ComfoAir Q range of units help to reduce fine pollen and carbon black particles in the supply air, however additional filtration such as NOx filters may be required. These need to be factored into the design pressure drop and are available from Zehnder.

Selecting an appropriate ComfoAir unit relevant to the air flow required can be done by simply using our product selector www.zehnderproductselector.co.uk

Key design considerations

- Minimum and maximum air flow design rates for the ComfoPost can be found within the Performance Data Table, ventilation pipework velocity must be < 3m/s.
- Ductwork should be sized accordingly to equate to the ComfoAir units spigot size.
- Thermal modelling to achieve the cooling/heating capacity for the specified ComfoPost relevant to the design flow temperatures within the appropriate Performance Data table. The recommended operating water temperature range is between 7 and 55°C.
- Maximum operating water pressure 6 bar.
- The ComfoPost can be installed horizontally or vertically but the condensate drain must always be in the lower position with the water connection on the side and not on the top or bottom. When installing vertically the airflow must NOT be directed downwards.
- Insulate intake/exhaust ductwork to a minimum of 25mm of insulating material, with a thermal conductivity of 0.04W/Mk.
- Insulate supply ductwork to a minimum of 10mm of insulating material, with a thermal conductivity of 0.04W/Mk.
- Insulate the water IN and water OUT pipework with the appropriate thickness and material.
- Enthalpy cube for the relevant ComfoAir Q or ComfoAir 160/180/200/350 unit used as standard.
- A buffer tank can be used to reduce the peak phases and ensure a quicker reaction time, requirement to be confirmed by thermal modeller.
- Ensure adequate attenuation is factored in at the higher flow rate.
- Ensure the intake/exhaust terminations are separated by a minimum of 2m and terminate to the external façade.
- Locate the MVHR unit on an external wall if possible.
- If a switch live boost is desired, then a relay linked to the Option Box is required when using the ComfoAir Q.
- The ComfoPost can be used in conjunction with corresponding ComfoWell, which can only be installed directly to it.
- Intake air from north facing orientation if possible.
- Don't intake air from south facing orientation.
 Don't intake air from underneath roof tiles or solar
- panels.
- Use a water filled siphon with a water lock of at least 100mm for the ComfoPost condensate drain.
- Use a dry trap on the ComfoAir MVHR units capable of achieving 500Pa of pressure.
- Due to the increased risk of corrosion, installations near the coast should be avoided

TO DOWNLOAD OUR COMFOAIR DATASHEET CLICK HERE

TO DOWNLOAD OUR

COMFOWELL DATASHEET

CLICK HERE



Contact information

Zehnder Group UK Ltd

Registered office: Concept House, Watchmoor Point, Camberley Surrey GU15 3AD Registered in England No.2296696

© Copyright Zehnder Group UK Ltd 2020

Head Office: 01276 605800 Technical Services: 01276 408 404 Email: enquiries@zehnder.co.uk Website: www.zehnder.co.uk





Zehnder ComfoPost CW6



ComfoPost CW6

The Zehnder ComfoPost is an air to water exchanger for use with ComfoWell air distribution connections. The ComfoWell connections allows for selection flexibility, offering a range of rigid circular ductwork or Zehnder ComfoTube semi-rigid ductwork to attached. The ComfoPost is available in a variety of sizes to heat or cool the air supplied by the Zehnder ventilation system.

The ComfoPost units are suitable for a wide range of airflows up to 166l/s (600m³hr), the CW6 is suitable for airflows up to 83.3l/s (300m³hr). The units are made of steel with aluminium and copper pipe forming the heating and cooling coils and are maintenance free.

Key Features

- Ideal for use with reversible heat pumps or chillers to meet SAP 10 or TM59 overheating demands
- Low pressure losses
- Filtered fresh supply air, not recycled stale air
- Suitable for use with the unique modular ComfoWell manifolds
- Suitable for horizontal or vertical installation
- Condensation water tray and drain as standard
- Suitable for Passive House application
- Corrosion resistant

Article Numbers

Description

Product Code

Zehnder ComfoPost CW6 post-treatment battery for heating and cooling with an airflow up to 300m ³ /h	398 480 002
---	-------------

Technical Specification

Height	230mm
Width	320mm
Depth	520mm
Water connection diameter (ø)	1/2"
Water connection type	BSPT male thread
Condensate drain diameter OD (ø)	14mm
Condensate connection type	Worm drive clip to fix to hose or crimped to copper pipe
ComfoWell range	ComfoWell 320
ComfoWell rigid round air connection options (ø)	125mm / 150mm / 160mm / 180mm
ComfoWell semi-rigid air connection options (ø)	6 x 75mm / 6 x 90mm / 2 x 90mm + 4 x 75mm
Material	Casing: Galvanised sheet steel Tubes: Copper Fins: Aluminium with hydrophilic treatment
Recommended operating water temperature range	7 to 55 °C
Recommended maximum operating air flow	<83.3l/s (<300m³hr)
Maximum thermal heating output	3.13kW*
Maximum thermal cooling output	2.8kW*
Maximum operating water pressure?	6 bar
Water volume capacity	0.6 Litres
Maintenance free	Yes
Weight	13.5 kg

3D System Layout





Height	230mm
Width	320mm
Depth	520mm
Weight	13.5 kg

Π

520

Top View

Decorative Radiators
 Comfortable indoor ventilation
 Heating and cooling ceiling systems
 Clean air solutions

Performance Data

						Hea	iting				Coc	oling
				HRV ex	changer			ERV ex	changer		HRV	ERV
Air cond	litions IN to ComfoPost	T °C		18	°C			17	°C		27°C	28°C
		RH %		2	5%			60)%		80%	55%
		AH		3.2	g/kg			7.3	g/kg		18.1 g/kg	13.1 g/kg
Wat	ter temperature IN	°C	55	50	45	40	55	50	45	40	7	7
	H ₂ O flow	l/h		6	00			6	00		600	600
	H ₂ O temperature _{OUT}	°C	52	48	43	39	52	48	43	38	10	9
³ /h)	$H_2O \Delta P$	kPa	9	10	10	10	9	10	10	10	12	12
44m	Air temperature OUT	°C	53	48	43	38	52	47	43	38	12	11
MUN /s (1	Air RH _{OUT}	%	4	5	6	8	9	11	14	17	100	96
401	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	9.1	7.9
flow	Air ΔP	Pa	9	9	9	9	9	9	9	9	17	13
Air	Condensation	l/h	-	-	-	-	-	-	-	-	1.7	2.1
	Sensible power	kW	-	-	-	-	-	-	-	-	0.74	0.4
	TOTAL POWER	kW	1.73	1.5	1.26	1.03	1.79	1.55	1.32	1.08	1.88	1.52
	H ₂ O flow	l/h		6	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	52	47	43	38	51	47	42	38	10	10
3/h)	$H_2O \Delta P$	kPa	9	10	10	10	9	10	10	10	12	12
216m	Air temperature _{OUT}	°C	50	46	41	37	50	46	41	37	14	13
l/s (3	Air RH _{OUT}	%	4	5	7	8	9	12	15	19	100	93
v 60	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	10.3	8.6
flov	Air ΔP	Pa	15	14	14	14	15	14	14	14	28	21
Air	Condensation	l/h	-	-	-	-	-	-	-	-	2.1	2.1
	Sensible power	kW	-	-	-	-	-	-	-	-	0.94	0.63
	TOTAL POWER	kW	2.35	2.03	1.71	1.39	2.43	2.1	1.78	1.46	2.35	1.94
	H ₂ O flow	l/h		6	00			6	00		600	600
	H ₂ O temperature _{OUT}	°C	51	46	42	38	51	46	42	37	11	10
n ³ /h)	H ₂ Ο ΔΡ	kPa	9	10	10	10	9	10	10	10	12	12
288r	Air temperature _{OUT}	°C	48	44	40	36	48	44	40	36	16	14
l/s (Air RH _{OUT}	%	5	6	7	9	11	13	17	20	99	90
v 80	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.3	9.2
flov	Air ∆P	Pa	21	21	21	21	21	21	21	21	41	30
Air	Condensation	l/h	-	-	-	-	-	-	-	-	2.4	2.2
	Sensible power	kW	-	-	-	-	-	-	-	-	1.1	0.85
	TOTAL POWER	kW	2.93	2.53	2.13	1.73	3.03	2.62	2.22	1.82	2.74	2.29
	H ₂ O flow	l/h		6	00			6	00		600	600
Ê	H ₂ O temperature _{OUT}	°C	51	46	42	37	51	47	42	38	11	10
m ³ /	H ₂ Ο ΔΡ	kPa	10	10	10	10	10	10	10	10	12	12
ML (300	Air temperature _{OUT}	°C	48	44	40	36	48	43	39	35	16	15
31/s	Air RH _{OUT}	%	5	6	7	9	10	12	15	19	99	90
MA)	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.4	9.3
flow	Air ∆P	Pa	23	23	23	22	23	23	23	22	44	32
Air	Condensation	l/h	-	-	-	-	-	-	-	-	2.4	2.2
	Sensible power	kW	-	-	-	-	-	-	-	-	1.12	0.89
	TOTAL POWER	kW	3.03	2.62	2.2	1.79	3 13	2.71	2.29	1.88	2.8	2.34

Initial temperature and humidity outdoor/indoor: winter 2°C 70% R.H. / 20°C 60% R.H.; summer 35°C 50% R.H. / 25°C 50% R.H. The calculations include the cold recovery efficiency of an enthalpy exchanger as extrapolated from the results provided by the PHI certification

Performance Data



Schematics





Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

CLICK HERE



Consultant specification

Specification

The air to water exchanger shall be constructed of galvanised sheet steel with copper tubes and aluminum fins with hydrophilic treatment to enhance thermal transfer. It shall be connected to the MVHR units supply ductwork with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm. It shall have the option for horizontal or vertical mounting.

The unit shall be manufactured by Zehnder.





Zehnder ComfoWell 320





Comfowell 320

The Zehnder ComfoWell 320 is a modular system consisting of attenuators, fine grade filters and active carbon filters all integrated for use with a rigid or semi-rigid ductwork approach. With a width of 320mm it can be used for connecting up to 6 ComfoTube connections. The systems compact dimensions ensure good sound absorption and also make it easy to clean. Rigid pipe can be connected to the end plate securely by utilising the gasket seal connection. All other components are fitted using the locking slide connections to form an airtight and robust seal.

Noise reduction can be improved by combining two attenuators together. Filters are available in ISO ePM1 >80% (F7) or ISO ePM1 >90% (F9) grade in addition to an odour neutralising active carbon filter.



Key Features

• Attenuator, fine grade filter, active carbon filter and manifold all combined into one space saving combination with the option to bespoke build exactly what is required.

• Easy to assemble thanks to its modular and compact design.

Article Numbers	
Description	Product Code
Attenuator	
Zehnder ComfoWell attenuator, CW-S 320	990 323 501
Manifold	
Zehnder ComfoWell manifold box CW-D 320	990 323 531
Filter Housing	
Zehnder ComfoWell filter housing CW-F 320	990 323 551
Mounting Plates	
Zehnder ComfoWell mounting plate, CW-M 320, 6 x 75mm connections	990 323 612
Zehnder ComfoWell mounting plate, CW-M 320, 6 x 90mm connections	990 323 613
End Plates	
Zehnder ComfoWell end plate, CW-P 320, ø 125mm	990 323 511
Zehnder ComfoWell end plate, CW-P 320, ø 150mm	990 323 562
Zehnder ComfoWell end plate, CW-P 320, ø 160mm	990 312 512
Zehnder ComfoWell end plate, CW-P 320, ø 180mm	990 312 527

Article Numbers

Spacer Eramo

Spacer Frame	
Zehnder ComfoWell spacer frame, CW-DF 320	990 323 538
Mounting Set	
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 160	990 323 570
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 200	990 323 517
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir Q350	990 323 647
Filters	
Filter for ComfoWell 320, CW-F7 320, ISO ePM1 >80% (F7), 1 Piece	990 323 603
Filter for ComfoWell 320, CW-F9 320, ISO ePM1 >90% (F9), 1 Piece	990 323 604
Filter for ComfoWell 320, CW-AC 320, active carbon filter, 1 Piece	990 323 605

Spacer Frame	
Zehnder ComfoWell spacer frame, CW-DF 320	990 323 538
Mounting Set	
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 160	990 323 570
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 200	990 323 517
Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir Q350	990 323 647
Filters	
Filter for ComfoWell 320, CW-F7 320, ISO ePM1 >80% (F7), 1 Piece	990 323 603
Filter for ComfoWell 320, CW-F9 320, ISO ePM1 >90% (F9), 1 Piece	990 323 604
Filter for ComfoWell 320, CW-AC 320, active carbon filter, 1 Piece	990 323 605

Technical Specification

Housing material	Galvanised Sheet Steel
Operating temperature range	-25 to +60 °C
Inner lining	Closed-cell melamine resin foam
Recommended maximum air volume	66.6l/s (240 m ³ /h) at normal ventilation level
Air tightness class to EN 1507:2006	В
Air tightness class to EN 12237:2003	В
Fire rating to ISO13501	C

Example Connections

Combination	ComfoAir 200 Left handed with mounting set, 2 x attenuators and 2 x 6 port ø 75mm mounting plates	Stand alone attenuator with 2x ø 160mm end plates	Stand alone manifold with 1 x ø 125mm end plate and 6 x ø 75mm mounting plate	Stand alone filter housing with 2 x ø 160m end plate	Stand alone attenuator and manifold combined with 1 x ø 160mm end plate and 6 x ø 75mm mounting plate	Stand alone 2 x attenuator with 1 x ø 160mm end plate and 6 x ø 75mm mounting plate
Individual Components						
Silencer	2 x Zehnder ComfoWell attenuator, CW-S 320	1 x Zehnder ComfoWell attenuator, CW-S 320			1 x Zehnder ComfoWell attenuator, CW-S 320	2 x Zehnder ComfoWell attenuator, CW-S 320
Manifold Box			1 x Zehnder ComfoWell manifold box, CW-D 320			
Filter Housing				1 x Zehnder ComfoWell filter housing, CW-F 320		
Mounting Plate -075	2 x Zehnder ComfoWell mounting plate, CW-M 320, 6 x 75mm connections		1 x Zehnder ComfoWell mounting plate, CW-M 320, 6 x 75mm connections		1 x Zehnder ComfoWell mounting plate, CW-M 320, 6 x 75mm connections	1 x Zehnder ComfoWell mounting plate, CW-M 320, 6 x 75mm connections
End Plate - ø 125			1 x Zehnder ComfoWell end plate, CW-P 320, o 125mm			
End Plate - ø160		2 x Zehnder ComfoWell end plate, CW-P 320, ø 125mm		2 x Zehnder ComfoWell end plate, CW-P 320, ø 160mm	1 x Zehnder ComfoWell end plate, CW-P 320, ø 160mm	1 x Zehnder ComfoWell end plate, CW-P 320, ø 160mm
Mounting Set 200	1 x Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 160					
Filter				1 x Filter for ComfoWell 320, CW-F9 320, ISO ePM1 >90% (F9), 1 Piece		

Dimensions

Zehnder ComfoWell attenuator, CW-S 320

Article number: 990 323 501

Description

Attenuator:

Zehnder ComfoWell attenuator CW-S 320. Rectangular compact attenuator with highly efficient sound insulation combined with low pressure losses. The attenuator can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

For cleaning purposes the sound absorbing element can be removed.

Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	506mm
Width	336mm
Depth	232.5mm
Weight	6.6 kg

Zehnder ComfoWell manifold box CW-D 320

Article number: 990 323 531

Description

Manifold Box:

Zehnder ComfoWell manifold box CW-D 320. Rectangular compact design with closed pore internal lining. Suitable for use with the mounting plate for ComfoTube 75mm x 6 connections, 90mm x 6 connections or a combination of 90mm x 2 and 75mm x 4 connections. The mounting plate can be mounted on the top or side of the manifold box. The airtight connection between components is via a clamping strip.

For cleaning purposes the manifold box side plate can be removed for easy access. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	233mm
Width	336mm
Depth	253.8mm
Weight	4.52 kg







Zehnder ComfoWell filter housing CW-F 320

Article number: 990 323 551

Description

Filter Housing:

Zehnder ComfoWell filter housing CW-F 220. Rectangular compact design for use with a fine pollen filter graded ISO ePM1 >80% (F7), a fine dust filter graded ISO ePM1 >90% (F9) or an active carbon filter to neutralise odours in the supply air duct run.

The filter elements are not included with the filter housing and need to be purchased separately. The filter housing can be used individually or in combination with all ComfoWell components. The airtight connection between components is via

a clamping strip.

Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

306mm
336mm
242.2mm
4.73 kg







Front view

336.0 242.2

Dimensions

Zehnder ComfoWell mounting plate CW-M 320

Article number: 990 323 613

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 320-6 x 90. Manifold mounting plate for connection of 6 x ComfoTube 90mm semi-rigid ducting. The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

Height	45.1mm
Width	336mm
Depth	230mm
Weight	<1.53 kg

Zehnder ComfoWell mounting plate CW-M 320

Article number: 990 323 612

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 320-6 x 75. Manifold mounting plate for connection of 6 x ComfoTube 75mm semi-rigid ducting. The mounting plate includes a protective film and the necessary mounting accessories.







Dimensions

Height	45.1mm
Width	336mm
Depth	230mm
Weight	<1.53 kg

Top View

Side view





Zehnder ComfoWell end plate CW-P 320 -ø 125

Article number: 990 323 511

42.3mm

336mm

230mm

125mm

Description

End Plate:

Dimensions

Height

Width

Depth

Diameter

Zehnder ComfoWell end plate CW-P 320 - DN125 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.



42.3-





Front view





Zehnder ComfoWell end plate CW-P 320 -ø 150mm

Article number: 990 323 562

Description

End Plate:

Zehnder ComfoWell end plate CW-P 320 - DN150 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	236mm
Depth	230mm
Diameter	150mm

Side view

Front view

Top View







42.3-



Dimensions

Zehnder ComfoWell end plate CW-P 320 -ø 160mm

Article number: 990 323 512

Description

End Plate:

Zehnder ComfoWell end plate CW-P 320 - DN160 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	236mm
Depth	230mm
Diameter	160mm

Zehnder ComfoWell end plate CW-P 320 -ø 180mm

Article number: 990 323 527

Description

End Plate:

Zehnder ComfoWell end plate CW-P 320 - DN180 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	236mm
Depth	230mm
Diameter	180mm





Zehnder ComfoWell spacer frame, CW-DF 320

Article number: 990 323 538

Description

Zehnder ComfoWell spacer frame CW-DF320. Rectangular frame for use in the event of uneven surfaces when connecting components and mounting plate (concreted in place) are at 90 degrees. The spacer frame includes the necessary mounting accessories.

27.8



Dimensions

Height	27.8mm
Width	336mm
Depth	230mm
Weight	1.02 kg

Top View

Side view

Front view



Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 160

Article number: 990 323 570

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 320 for direct mounting to the ComfoAir 160 ventilation unit. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets)







Height	94.3mm
Width	336mm
Depth	230mm
Weight	2.3 kg

Side view

Front view



Dimensions

Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAir 200

Article number: 990 323 517

Description

Mounting set:	Sid
A special mounting set is available for the Zehnder	
ComfoWell 320 for direct mounting to the ComfoAir	
200 ventilation unit.	
The mounting set includes all the necessary	
accessories (screws, brackets and mounting	Fro
brackets).	

Dimensions

Height	42mm
Width	336mm
Depth	230mm
Weight	1.8 kg

Zehnder ComfoWell mounting set, CW-K 320, for Zehnder ComfoAirQ 350

Article number: 990 323 647

Description

Mounting set:	;
A special mounting set is available for the Zehnder	
ComfoWell 320 for direct mounting to the	
ComfoAir Q 350 ventilation unit.	
The mounting set includes all the necessary	
accessories (screws, brackets and mounting	I
brackets).	

Dimensions

Height	61.8mm
Width	336mm
Depth	510.5mm
Weight	3.5 kg





Pressure Curve

Comfowell 320



2 x Attenuator (CW-S 320) stacked with 2 x 160mm end plates (CW-P 320)

1 x Filter housing (CW-F 320) with 2 x 160mm end plates (CW-P 320) and filter (CW-F7 320)	
1 x Filter housing (CW-F 320) with 2 x 160mm end plates (CW-P 320) and filter (CW-AC 320)	
1 x Filter housing (CW-F 420) with 2 x 160mm end plates (CW-P 420) and filter (CW-F9 320)	

For use with

Our range of Comfowell units can be used in conjunction with our Zehnder ComfoTube ø 75mm and ø 90mm semi-rigid ductwork.



BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY

Sound Data

Comfowell 320

Combination	Octave Band (Hz) Insertion Loss, dB									
Combination	63	125	250	500	1000	2000	4000	8000		
1 x Attenuator (CW-S 320) with 2 x 160mm end plates (CW-P 320)	4,6	5,6	9,2	6,5	4,6	23,0	17,4	23,8		
2 x Attenuator (CW-S 320) stacked with 2 x 160mm end plates (CW-P 320)	6,0	10,4	17,8	14,1	13,6	47,4	36,8	34,9		

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by following the link below.







Consultant specification

Specification

The semi-rigid ductwork manifold shall be constructed of galvanised sheet steel with a closed-cell melamine resin foam inner lining to prevent dust collection and have a fire class C rating according to EN ISO13501.

It shall be of modular construction with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm.

It shall have the option of a mounting set for direct connection to the mechanical ventilation with heat recovery unit. The components shall be tested to BS EN 1507:2006 and BS EN 12237:2003 for airtightness and have removable elements to provide access for cleaning.





Zehnder ComfoPost CW8*



ComfoPost CW8

The Zehnder ComfoPost is an air to water exchanger for use with ComfoWell air distribution connections. The ComfoWell connections allows for selection flexibility, offering a range of rigid circular ductwork or Zehnder ComfoTube semi-rigid ductwork to attached. The ComfoPost is available in a variety of sizes to heat or cool the air supplied by the Zehnder ventilation system.

The ComfoPost units are suitable for a wide range of airflows up to 166l/s (600m³hr), the CW8 is suitable for airflows up to 111.1l/s (400m³hr). The units are made of steel with aluminium and copper pipe forming the heating and cooling coils and are maintenance free.

Key Features

- Ideal for use with reversible heat pumps or chillers to meet SAP 10 or TM59 overheating demands
- Low pressure losses
- Filtered fresh supply air, not recycled stale air
- Suitable for use with the unique modular ComfoWell manifolds
- Suitable for horizontal or vertical installation
- Condensation water tray and drain as standard
- Suitable for Passive House application
- Corrosion resistant

Article Numbers

Description

Product Code

Zehnder ComfoPost CW8 post-treatment battery for heating and cooling with an airflow up to 400m ³ /h	399 000 004
---	-------------

Technical Specification

Height	230mm
Width	420mm
Depth	520mm
Water connection diameter (ø)	1/2"
Water connection type	BSPT male thread
Condensate drain diameter OD (ø)	14mm
Condensate connection type	Worm drive clip to fix to hose or crimped to copper pipe
ComfoWell range	ComfoWell 420
ComfoWell rigid round air connection options (ø)	125mm / 150mm / 160mm / 180mm / 200mm
ComfoWell semi-rigid air connection options (ø)	8 x 75mm / 8 x 90mm / 4 x 90mm + 4 x 75mm
Material	Casing: Galvanised sheet steel Tubes: Copper Fins: Aluminium with hydrophilic treatment
Recommended operating water temperature range	7 to 55 °C
Recommended maximum operating air flow	<111.1l/s (<400m³hr)
Maximum thermal heating output	4.18kW*
Maximum thermal cooling output	3.73kW*
Maximum operating water pressure?	6 bar
Water volume capacity	0.8 Litres
Maintenance free	Yes
Weight	16 kg

3D System Layout





Height	230mm
Width	420mm
Depth	520mm
Weight	16 kg







Performance Data

			Heating					Coo	ling			
				HRV ex	changer		ERV exchanger				HRV	ERV
Air con	ditions IN to ComfoPost	T °C	18 °C		17 °C				27°C	28°C		
		RH %	25%		60%			80%	55%			
		AH		3.2	g/kg			7.3	g/kg		18.1 g/kg	13.1 g/kg
Wa	ater temperature IN	°C	55	50	45	40	55	50	45	40	7	7
	H ₂ O flow	l/h		60	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	51	47	42	38	51	47	42	38	11	10
3/h)	$H_2O \Delta P$	kPa	11	11	11	11	11	11	11	12	13	14
16m	Air temperature _{OUT}	°C	52	47	43	38	52	47	43	38	13	11
MUN /s (2	Air RH _{OUT}	%	4	5	6	8	9	11	14	18	100	95
MINI 601	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	9.3	8.0
flow	Air ΔP	Pa	9	9	9	9	9	9	9	9	17	13
Air	Condensation	l/h	-	-	-	-	-	-	-	-	2.3	1.3
	Sensible power	kW	-	-	-	-	-	-	-	-	1.03	1.23
	TOTAL POWER	kW	2.48	2.14	1.8	1.47	2.56	2.22	1.88	1.54	2.64	2.15
	H ₂ O flow	l/h		60	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	50	46	42	37	50	46	42	37	12	11
n³/h)	$H_2O \Delta P$	kPa	11	11	11	11	11	11	11	12	13	14
288n	Air temperature _{OUT}	°C	50	46	42	37	50	46	41	37	14	13
l/s ()	Air RH _{OUT}	%	4	5	6	8	9	12	15	19	100	93
v 80	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	10.3	8.6
flow	Air ΔP	Pa	13	13	13	13	13	13	13	13	25	19
Air	Condensation	l/h	-	-	-	-	-	-	-	-	2.7	1.6
	Sensible power	kW	-	-	-	-	-	-	-	-	1.26	1.5
	TOTAL POWER	kW	3.14	2.72	2.29	1.86	3.25	2.82	2.39	1.96	3.13	2.58
	H ₂ O flow	l/h		60	00			60	00		600	600
~	H ₂ O temperature _{OUT}	°C	50	45	41	37	49	45	41	37	12	
m³/h	H ₂ Ο ΔΡ	kPa	11	11	11	11	11	11	11	12	14	
(360	Air temperature OUT	°C	49	45	40	36	49	44	40	36	16	14
01/s	Air RH _{OUT}	%	4	6	7	9	10	13	16	20	99	91
۲ I	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.1	9.1
flov	Air ΔP	Pa	18	17	17	17	18	17	17	17	34	25
Air	Condensation	l/h	-	-	-	-	-	-	-	-	3.1	1.7
	Sensible power	kW	-	-	-	-	-	-	-	-	1.42	1.74
	TOTAL POWER	kW	3.74	3.23	2.72	2.21	3.87	3.35	2.83	2.32	3.53	2.94
	H ₂ O flow	l/h		60	00			60	00		600	600
(H	H ₂ O temperature _{OUT}	°C	49	45	41	37	49	45	41	38	11	11
ĨE O	H ₂ Ο ΔΡ	kPa	11	11	12	12	11	11	12	12	14	14
MU (40	Air temperature OUT	°C	48	44	40	36	48	44	40	35	16	15
XIMU .11/s	Air RH _{OUT}	%	5	6	7	9	11	13	16	20	99	90
MA 111	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	9.1	9.3
No	Air ΔP	Pa	21	21	20	20	21	21	20	20	39	29
Air 1	Condensation	l/h	-	-	-	-	-	-	-	-	1.7	1.8
	Sensible power	kW	-	-	-	-	-	-	-	-	1.5	1.8
	TOTAL POWER	kW	4.06	3.5	2.95	2.4	4.18	3.63	3.07	2.51	3.73	3.11

Initial temperature and humidity outdoor/indoor: winter 2°C 70% R.H. / 20°C 60% R.H.; summer 35°C 50% R.H. / 25°C 50% R.H. The calculations include the cold recovery efficiency of an enthalpy exchanger as extrapolated from the results provided by the PHI certification

Top View

Example Connection

Performance Data





For use with Zehnder ComfoWell 420

For Use With

Our range of ComfoPost products can be used in conjunction with our ComfoAir units, complete with enthalpy cube for improved sensible cooling capacity. The unit shall be manufactured by Zehnder.



BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY CLICK HERE

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

TO VISIT OUR DOWNLOAD PAGE



Consultant specification

Specification

The air to water exchanger shall be constructed of galvanised sheet steel with copper tubes and aluminum fins with hydrophilic treatment to enhance thermal transfer. It shall be connected to the MVHR units supply ductwork with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm. It shall have the option for horizontal or vertical mounting.

The unit shall be manufactured by Zehnder.





Comfowell 420

The Zehnder ComfoWell 420 is a modular system consisting of attenuators, fine grade filters and active carbon filters all integrated for use with a rigid or semi-rigid ductwork approach. With a width of 420mm it can be used for connecting up to 8 ComfoTube connections. The systems compact dimensions ensure good sound absorption and also make it easy to clean. Rigid pipe can be connected to the end plate securely by utilising the gasket seal connection. All other components are fitted using the locking slide connections to form an airtight and robust seal.

Noise reduction can be improved by combining two attenuators together. Filters are available in ISO ePM1 >80% (F7) or ISO ePM1 >90% (F9) grade in addition to an odour neutralising active carbon filter.



Key Features

- build exactly what is required.
- Easy to assemble thanks to its modular and compact design. •

Article Numbers

Description

Attenuator

Zehnder ComfoWell attenuator, CW-S 420	990 323 504
Manifold	
Zehnder ComfoWell manifold box CW-D 420	990 323 620
Filter Housing	
Zehnder ComfoWell filter housing CW-F 420	990 323 554
Mounting Plates	
Zehnder ComfoWell mounting plate, CW-M 420, 8 x 75mm connections	990 323 621
Zehnder ComfoWell mounting plate, CW-M 420, 8 x 90mm connections	990 323 622
Zehnder ComfoWell mounting plate, CW-M 420, 4 x 90mm + 4 x 75mm connections	990 323 623
End Plates	
Zehnder ComfoWell end plate, CW-P 420, ø 125mm	990 323 625
Zehnder ComfoWell end plate, CW-P 420, ø 150mm	990 323 626

Zehnder ComfoWell end plate, CW-P 420, ø 125mm
Zehnder ComfoWell end plate, CW-P 420, ø 150mm
Zehnder ComfoWell end plate, CW-P 420, ø 160mm
Zehnder ComfoWell end plate, CW-P 420, ø 180mm
Zehnder ComfoWell end plate, CW-P 420, ø 200mm

Zehnder ComfoWell 420





Attenuator, fine grade filter, active carbon filter and manifold all combined into one space saving combination with the option to bespoke

Product Code

990 323 627 990 323 628 990 323 629

Example Connections

990 323 652

Combination Options	ComfoAir Q350 right handed with mounting set, 2 x attenuators and 2 x 8 port ø 75mm mounting plates	Stand alone attenuator with 2 x ø 160mm end plates	Stand alone manifold with 1 x ø 160mm end plate and 8 x ø 75mm mounting plate	Stand alone filter housing with 2 x ø 160mm	Stand alone silencer and manifold combined with 1 x ø 160mm end plate and 8 x ø 75mm mounting plate	Stand alone 2 x attenuator with 1 x ø 160mm end plate and 8 x ø 75mm mounting plate
Individual Components						
Attenuator	2 x Zehnder ComfoWell attenuator, CW-S 420	1 x Zehnder ComfoWell attenuator, CW-S 420			1 x Zehnder ComfoWell attenuator, CW-S 420	2 x Zehnder ComfoWell attenuator, CW-S 420
Manifold Box			1 x Zehnder ComfoWell manifold box, CW-D 420			
Filter Housing				1 x Zehnder ComfoWell filter housing, CW-F 420		
Mounting Plate -e75	2 x Zehnder ComfoWell mounting plate, CW-M 420, 8 x 75mm connections		1 x Zehnder ComfoWell mounting plate, CW-M 420, 8 x 75mm connections		1 x Zehnder ComfoWell mounting plate, CW-M 420, 8 x 75mm connections	1 x Zehnder ComfoWell mounting plate, CW-M 420, 8 x 75mm connections
End Plate - ø 160		2 x Zehnder ComfoWell end plate, CW-P 420, ø 160mm	1 x Zehnder ComfoWell end plate, CW-P 420, ø 160mm	2 x Zehnder ComfoWell end plate, CW-P 420, ø 160mm	1 x Zehnder ComfoWell end plate, CW-P 420, ø 160mm	1 x Zehnder ComfoWell end plate, CW-P 420, ø 160mm
Mounting Set	1 x Zehnder ComfoWell mounting set, CW-K 420, for Zehnder ComfoAir Q350					
Filter				1 x Filter for ComfoWell 420, CW-F9 420, ISO ePM1 >90% (F9), 1 Piece		

Article Numbers

Spacer Frame	
Zehnder ComfoWell spacer frame, CW-DF 420	990 323 624
Mounting Set	
Zehnder ComfoWell mounting set, CW-K 420, for Zehnder ComfoAir Q350	990 323 648
Zehnder ComfoWell mounting set, CW-K 420, for Zehnder ComfoAir Q450/600	990 323 641
Filters	
Filter for ComfoWell 420, CW-F7 420, ISO ePM1 >80% (F7), 1 Piece	990 323 650
Filter for ComfoWell 420, CW-F9 420, ISO ePM1 >90% (F9), 1 Piece	990 323 651

Technical Specification

Filter for ComfoWell 420, CW-AC 420, active carbon filter, 1 Piece

Housing material	Galvanised Sheet Steel
Operating temperature range	-25 to +60 °C
Inner lining	Closed-cell melamine resin foam
Recommended maximum air volume	88.8l/s (320 m³/h) at normal ventilation level
Air tightness class to EN 1507:2006	С
Air tightness class to EN 12237:2003	С
Fire rating to ISO13501	С

Zehnder ComfoWell attenuator, CW-S 420

Article number: 990 323 504

Description

Attenuator:

Zehnder ComfoWell attenuator CW-S 420. Rectangular compact attenuator with highly efficient sound insulation combined with low pressure losses. The attenuator can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

For cleaning purposes the sound absorbing element can be removed. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	506mm	_
Width	436mm	
Depth	235mm	
Weight	6 kg	

Side view

Front view







Zehnder ComfoWell manifold box CW-D 420

Article number: 990 323 620

Description

Manifold Box:

Zehnder ComfoWell manifold box CW-D 420. Rectangular compact design with closed pore internal lining. Suitable for use with the mounting plate for ComfoTube 75mm x 8 connections, 90mm x 8 connections or a combination of 90mm x 4 and 75mm x 4 connections. The mounting plate can be mounted on the top or side of the manifold box. The airtight connection between components is via a clamping strip.

For cleaning purposes the manifold box side plate can be removed for easy access. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	233mm
Width	436mm
Depth	259 mm
Weight	4.7 kg





■ Decorative Radiators ■ Comfortable indoor ventilation ■ Heating and cooling ceiling systems ■ Clean air solutions

Dimensions

Zehnder ComfoWell filter housing CW-F 420

Article number: 990 323 554

Description

Filter Housing:

Zehnder ComfoWell filter housing CW-F 420. Rectangular compact design for use with a fine pollen filter graded ISO ePM1 >80% (F7), a fine dust filter graded ISO ePM1 >90% (F9) or an active carbon filter to neutralise odours in the supply air duct run. The filter elements are not included with the filter housing and need to be purchased separately. The filter housing can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	306mm
Width	436mm
Depth	242.2mm
Weight	1.32 kg

Zehnder ComfoWell mounting plate CW-M 420

Article number: 990 323 621

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 420-8 x 75. Manifold mounting plate for connection of 8 x ComfoTube 75mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

Height	45mm
Width	436mm
Depth	230mm
Weight	<1.5 kg



Zehnder ComfoWell mounting plate CW-M 420

Article number: 990 323 622

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 420-8 x 90. Manifold mounting plate for connection of 8 x ComfoTube 90mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.





Front view

Side



Dimensions

Height	45mm
Width	436mm
Depth	230mm
Weight	<1.5 kg



Zehnder ComfoWell mounting plate CW-M 420

Article number: 990 323 623

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 2 x 90 and 4 x 75. Manifold mounting plate for connection of 2 x 90 and 4 x 75 semi-rigid ducting. The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

Height	45mm
Width	436mm
Depth	230mm
Weight	<1.53 kg

Side view



Front view





Dimensions

Zehnder ComfoWell end plate CW-P 420 -ø 125

Article number: 990 323 625

Description

End Plate:

Zehnder ComfoWell end plate CW-P 420 - DN125 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	436mm
Depth	230mm
Diameter	125mm

Zehnder ComfoWell end plate CW-P 420 -ø 150mm

Article number: 990 323 626

Description

End Plate:

Zehnder ComfoWell end plate CW-P 420 - DN150 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	436mm
Depth	230mm
Diameter	150mm

Top View





Zehnder ComfoWell end plate CW-P 420 -ø 160mm

Article number: 990 323 627

Description End Plate:

Zehnder ComfoWell end plate CW-P 420 - DN160 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.



42.3

Side view

Front view





Dimensions

Height	42.3mm
Width	436mm
Depth	230mm
Diameter	160mm





Zehnder ComfoWell end plate CW-P 420 -ø 180mm

Article number: 990 323 628

Description

End Plate:

Zehnder ComfoWell end plate CW-P 420 - DN180 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	436mm
Depth	230mm
Diameter	180mm





Side view



42.3

Front view



Dimensions

Zehnder ComfoWell end plate CW-P 420 -ø 200mm

Article number: 990 323 629

Description

End Plate:

Zehnder ComfoWell end plate CW-P 420 - DN200 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	436mm
Depth	230mm
Diameter	200mm

Zehnder ComfoWell spacer frame, CW-DF 420

Article number: 990 323 624

Description

Zehnder ComfoWell spacer frame CW-DF420. Rectangular frame for use in the event of uneven surfaces when connecting components and mounting plate (concreted in place) are at 90 degrees. The spacer frame includes the necessary mounting accessories.

Dimensions

Height	27.8mm	
Width	436mm	_
Depth	230mm	
Weight	1.12 kg	-





Front view



Top View

Zehnder ComfoWell mounting set, CW-K 420, for Zehnder ComfoAir Q350

Article number: 990 323 648

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 420 for direct mounting to the ComfoAir Q350 ventilation units. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets).

Side view

Front view

Top View

Side view

Front view

Top View





Height	61.8mm
Width	436mm
Depth	510.5mm
Weight	4.04 kg



Zehnder ComfoWell mounting set, CW-K 420, for Zehnder ComfoAir Q450/600

Article number: 990 323 641

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 420 for direct mounting to the ComfoAir Q450/ ComfoAir Q600 ventilation units. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets).



6(,8

61.6

J C 6.8



61.8



Pressure Curve

Comfowell 420



1 x Attenuator (CW-S 420) with 2 x 160mm end plates (CW-P 420) 1 x Filte 2 x Attenuator (CW-S 420) stacked with 2 x 160mm end plates (CW-P 420) 1 x Filte 1 x Filte

Sound Data

Comfowell 420

Combination	Octave Band (Hz) Insertion Loss, dB							
	63	125	250	500	1000	2000	4000	8000
1 x Attenuator (CW-S 420) with 2 x 160mm end plates (CW-P 420)	3.0	4.6	6.4	10.6	8,1	14,4	7,8	6,7
2 x Attenuator (CW-S 420) stacked with 2 x 160mm end plates (CW-P 420)	4,8	11,7	16,7	23,3	17,3	32,4	21,8	18,3

Dimensions

Height	61.8mm
Width	436mm
Depth	510.5mm
Weight	4.04 kg

er housing (CW-F 420) with 2 x 160mm end plates (CW-P 420) and filter (CW-F7 420)	
er housing (CW-F 420) with 2 x 160mm end plates (CW-P 420) and filter (CW-AC 420)	_
er housing (CW-F 420) with 2 x 160mm end plates (CW-P 420) and filter (CW-F9 420)	_

For use with

Our range of Comfowell units can be used in conjunction with our Zehnder ComfoTube ø 75mm and ø 90mm semi-rigid ductwork.



TO VIEW OUR COMFOTUBE INFORMATION CLICK HERE

BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY

CLICK HERE

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

TO VISIT OUR DOWNLOAD PAGE



Consultant specification

Specification

The semi-rigid ductwork manifold shall be constructed of galvanised sheet steel with a closed-cell melamine resin foam inner lining to prevent dust collection and have a fire class C rating according to EN ISO13501.

It shall be of modular construction with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm.

It shall have the option of a mounting set for direct connection to the mechanical ventilation with heat recovery unit. The components shall be tested to BS EN 1507:2006 and BS EN 12237:2003 for airtightness and have removable elements to provide access for cleaning.





Zehnder ComfoPost CW10*



ComfoPost CW10

The Zehnder ComfoPost is an air to water exchanger for use with ComfoWell air distribution connections. The ComfoWell connections allows for selection flexibility, offering a range of rigid circular ductwork or Zehnder ComfoTube semi-rigid ductwork to attached. The ComfoPost is available in a variety of sizes to heat or cool the air supplied by the Zehnder ventilation system.

The ComfoPost units are suitable for a wide range of airflows up to 166l/s (600m³hr), the CW10 is suitable for airflows up to 138.9l/s (500m³hr) The units are made of steel with aluminium and copper pipe forming the heating and cooling coils and are maintenance free.

Key Features

- Ideal for use with reversible heat pumps or chillers to meet SAP 10 or TM59 overheating demands
- Low pressure losses
- Filtered fresh supply air, not recycled stale air
- Suitable for use with the unique modular ComfoWell manifolds
- Suitable for horizontal or vertical installation
- · Condensation water tray and drain as standard
- Suitable for Passive House application
- Corrosion resistant

Article Numbers

Description

Product Code

Zernider Contro-Ost CW to post-treatment battery for heating and cooling with an antow up to 500m /m 596 460	30 003
--	--------

Technical Specification

Height	230mm				
Width	520mm				
Depth	520mm				
Water connection diameter (ø)	1/2"				
Water connection type	BSPT male thread				
Condensate drain diameter OD (ø)	14mm				
Condensate connection type	Worm drive clip to fix to hose or crimped to copper pipe				
ComfoWell range	ComfoWell 520				
ComfoWell rigid round air connection options (ø)	150mm / 160mm / 180mm / 200mm				
ComfoWell semi-rigid air connection options (ø)	10 x 75mm / 10 x 90mm / 4 x 90mm + 6 x 75mm				
Material	Casing: Galvanised sheet steel Tubes: Copper Fins: Aluminium with hydrophilic treatment				
Recommended operating water temperature range	7 to 55 °C				
Recommended maximum operating air flow	<138.9l/s (<500m³hr)				
Maximum thermal heating output	5.21kW*				
Maximum thermal cooling output	4.57kW*				
Maximum operating water pressure?	6 bar				
Water volume capacity	1 Litres				
Maintenance free	Yes				
Weight	19 kg				

3D System Layout





Height	230mm
Width	520mm
Depth	520mm
Weight	19 kg







Performance Data

			Heating					Coo	ling			
			HRV exchanger			ERV exchanger			HRV	ERV		
Air cond	itions IN to ComfoPost	T °C	18 °C				17 °C			27°C	28°C	
		RH %	25%				60%			80%	55%	
		AH		3.2	g/kg			7.3	g/kg		18.1 g/kg	13.1 g/kg
Wat	ter temperature IN	°C	55	50	45	40	55	50	45	40	7	7
	H ₂ O flow	l/h		6	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	50	46	42	37	50	46	41	37	12	11
3/h)	$H_2O \Delta P$	kPa	12	12	13	13	12	13	13	13	16	16
88m	Air temperature OUT	°C	52	47	42	38	51	47	42	38	13	12
MUN /s (2	Air RH _{OUT}	%	4	5	6	8	9	11	14	18	100	95
11NI 801	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	9.6	8.2
flow	Air ΔP	Pa	9	9	9	9	9	9	9	9	18	13
Air	Condensation	l/h	-	-	-	-	-	-	-	-	3	1.7
	Sensible power	kW	-	-	-	-	-	-	-	-	1.33	1.59
	TOTAL POWER	kW	3.27	2.82	2.38	1.94	3.38	2.93	2.48	2.04	3.41	2.78
	H ₂ O flow	l/h		6	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	49	45	41	37	49	45	41	36	13	12
n³/h)	$H_2O \Delta P$	kPa	12	13	13	13	12	13	13	13	15	16
360r	Air temperature OUT	°C	50	46	41	37	50	46	41	37	15	13
l/s (Air RH _{OUT}	%	4	5	6	8	9	12	15	19	100	93
100	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	10.4	8.7
Nol	Air ΔP	Pa	12	12	12	12	12	12	12	12	24	18
Air 1	Condensation	l/h	-	-	-	-	-	-	-	-	3.4	1.9
	Sensible power	kW	-	-	-	-	-	-	-	-	1.55	1.86
	TOTAL POWER	kW	3.93	3.39	2.86	2.32	4.05	3.52	2.98	2.44	3.86	3.19
	H ₂ O flow	l/h		6	00			60	00		600	600
-	H ₂ O temperature _{OUT}	°C	48	44	40	36	48	44	40	36	13	12
m³/h	$H_2O \Delta P$	kPa	12	13	13	13	12	12	13	13	15	15
4321	Air temperature OUT	°C	49	45	41	36	49	45	40	36	16	14
) s/l(Air RH _{OUT}	%	4	5	7	9	10	12	16	19	99	92
120	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.0	9.1
flow	Air ∆P	Pa	16	15	15	15	16	16	15	15	30	22
Air	Condensation	l/h	-	-	-	-	-	-	-	-	3.7	2.1
	Sensible power	kW	-	-	-	-	-	-	-	-	1.7	2.09
	TOTAL POWER	kW	4.52	3.91	3.29	2.67	4.67	4.05	3.43	2.81	4.25	3.54
	H ₂ O flow	l/h		6	00			60	00		600	600
Ê	H ₂ O temperature _{OUT}	°C	48	44	40	36	47	44	40	36	14	12
0 m ³ /	$H_2O \Delta P$	kPa	13	13	13	13	13	13	13	13	16	16
IM (500	Air temperature _{OUT}	°C	48	44	40	36	48	44	39	35	16	15
UMU 91/s	Air RH _{OUT}	%	5	6	7	9	11	13	16	20	99	90
MAX 138.	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.6	9.4
NO	Air ΔP	Pa	19	19	19	19	19	19	19	19	37	27
Air fl	Condensation	l/h	-	-	-	-	-	-	-	-	3.9	2.2
4	Sensible power	kW	-	-	-	-	-	-	-	-	1.83	2.3
	TOTAL POWER	kW	5.06	4 37	3.67	2.98	5 21	4.52	3.82	3.13	4 57	3.82

Initial temperature and humidity outdoor/indoor: winter 2°C 70% R.H. / 20°C 60% R.H.; summer 35°C 50% R.H. / 25°C 50% R.H. The calculations include the cold recovery efficiency of an enthalpy exchanger as extrapolated from the results provided by the PHI certification

Performance Data



Schematics





CLICK HERE

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

CLICK HERE







Consultant specification

Specification

The air to water exchanger shall be constructed of galvanised sheet steel with copper tubes and aluminum fins with hydrophilic treatment to enhance thermal transfer. It shall be connected to the MVHR units supply ductwork with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm. It shall have the option for horizontal or vertical mounting.

The unit shall be manufactured by Zehnder.



Zehnder Group UK Limited · Concept House, Watchmoor Point · Camberley · Surrey · GU15 3AD T +44 1276 408404 · info@zehnder.co.uk · www.zehnder.co.uk



Zehnder ComfoWell 520





Comfowell 520

The Zehnder ComfoWell 520 is a modular system consisting of attenuators, fine grade filters and active carbon filters all integrated for use with a rigid or semi-rigid ductwork approach. With a width of 520mm it can be used for connecting up to 10 ComfoTube connections. The systems compact dimensions ensure good sound absorption and also make it easy to clean. Rigid pipe can be connected to the end plate securely by utilising the gasket seal connection. All other components are fitted using the locking slide connections to form an airtight and robust seal.

Noise reduction can be improved by combining two attenuators together. Filters are available in ISO ePM1 >80% (F7) or ISO ePM1 >90% (F9) grade in addition to an odour neutralising active carbon filter.



Key Features

• Attenuator, fine grade filter, active carbon filter and manifold all combined into one space saving combination with the option to bespoke build exactly what is required.

• Easy to assemble thanks to its modular and compact design.

Article Numbers

Description	Product Code
Attenuator	
Zehnder ComfoWell attenuator, CW-S 520	990 323 502
Manifold	
Zehnder ComfoWell manifold box CW-D 520	990 323 532
Filter Housing	
Zehnder ComfoWell filter housing CW-F 520	990 323 552
Mounting Plates	
Zehnder ComfoWell mounting plate, CW-M 520, 10 x 75mm connections	990 323 614
Zehnder ComfoWell mounting plate, CW-M 520, 10 x 90mm connections	990 323 615
End Plates	
Zehnder ComfoWell end plate, CW-P 520, ø 150mm	990 323 568
Zehnder ComfoWell end plate, CW-P 520, ø 160mm	990 323 564
Zehnder ComfoWell end plate, CW-P 520, ø 180mm	990 312 513
Zehnder ComfoWell end plate, CW-P 520, ø 200mm	990 312 514

Article Numbers

Spacer Frame

Zehnder ComfoWell spacer frame, CW-DF 520	990 323 539
Mounting Set	
Zehnder ComfoWell mounting set, CW-K 520, for Zehnder ComfoAir Q350	990 323 649
Zehnder ComfoWell mounting set, CW-K 520, for Zehnder ComfoAir Q450/600	990 323 646
Filters	
Filter for ComfoWell 520, CW-F7 520, ISO ePM1 >80% (F7), 1 Piece	990 323 606
Filter for ComfoWell 520, CW-F9 520, ISO ePM1 >90% (F9), 1 Piece	990 323 607
Filter for ComfoWell 520, CW-AC 520, active carbon filter, 1 Piece	990 323 608

Technical Specification

Housing material	Galvanised Sheet Steel
Operating temperature range	-25 to +60 °C
Inner lining	Closed-cell melamine resin foam
Recommended maximum air volume	111.1l/s (400 m ³ /h) at normal ventilation level
Air tightness class to EN 1507:2006	C
Air tightness class to EN 12237:2003	C
Fire rating to ISO13501	С

Example Connections

Ν						
Combination Options	ComfoAir Q450 right handed with mounting set, 2 x attenuators and 2 x 10 port ø 75mm mounting plates	Stand alone attenuator with 2 x ø 180mm end plates	Stand alone manifold with 1 x ø 180mm end plate and 10 x ø 90mm mounting plate	Stand alone filter housing with 2 x ø 180mm end plate	Stand alone silencer and manifold combined with 1 x ø 180mm end plate and 10 x ø 90mm mounting plate	Stand alone 2 x attenuator with 1 x ø 180mm end plate and 10 x ø 90mm mounting plate
Individual Components						
Attenuator	2 x Zehnder ComfoWell attenuator, CW-S 520	1 x Zehnder ComfoWell attenuator, CW-S 520			1 x Zehnder ComfoWell attenuator, CW-S 520	2 x Zehnder ComfoWell attenuator, CW-S 520
Manifold Box			1 x Zehnder ComfoWell manifold box, CW-D 520			
Filter Housing				1 x Zehnder ComfoWell filter housing, CW-F 520		
Mounting Plate -ø75	2 x Zehnder ComfoWell mounting plate, CW-M 520, 10 x 75mm connections					
Mounting Plate -ø90			1 x Zehnder ComfoWell mounting plate, CW-M 520, 10 x 90mm connections		1 x Zehnder ComfoWell mounting plate, CW-M 520, 10 x 90mm connections	1 x Zehnder ComfoWell mounting plate, CW-M 520, 10 x 90mm connections
End Plate - ø 180		2 x Zehnder ComfoWell end plate, CW-P 520, ø 180mm	1 x Zehnder ComfoWell end plate, CW-P 520, ø 180mm	2 x Zehnder ComfoWell end plate, CW-P 520, ø 180mm	1 x Zehnder ComfoWell end plate, CW-P 520, ø 180mm	1 x Zehnder ComfoWell end plate, CW-P 520, ø 180mm
Mounting Set	1 x Zehnder ComfoWell mounting set, CW-K 520, for Zehnder ComfoAir Q450/600					
Filter				1 x Filter for ComfoWell 520, CW-F9 520, ISO ePM1 >90% (F9), 1 Piece		

Dimensions

Zehnder ComfoWell attenuator, CW-S 520

Article number: 990 323 502

Description

Attenuator:

Zehnder ComfoWell attenuator CW-S 520. Rectangular compact attenuator with highly efficient sound insulation combined with low pressure losses. The attenuator can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

For cleaning purposes the sound absorbing element can be removed. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	506mm
Width	536mm
Depth	232.5mm
Weight	8.2 kg

Zehnder ComfoWell manifold box CW-D 520

Article number: 990 323 532

Description

Manifold Box:

Zehnder ComfoWell manifold box CW-D 520. Rectangular compact design with closed pore internal lining. Suitable for use with the mounting plate for ComfoTube 75mm x 10 connections, 90mm x 10 connections or a combination of 90mm x 4 and 75mm x 6 connections. The mounting plate can be mounted on the top or side of the manifold box. The airtight connection between components is via a clamping strip.

For cleaning purposes the manifold box side plate can be removed for easy access. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	233mm
Width	536mm
Depth	259 mm
Weight	5.42 kg



Top View



Zehnder ComfoWell filter housing CW-F 520

Article number: 990 323 552

Description

Filter Housing:

Zehnder ComfoWell filter housing CW-F 520. Rectangular compact design for use with a fine pollen filter graded ISO ePM1 >80% (F7), a fine dust filter graded ISO ePM1 >90% (F9) or an active carbon filter to neutralise odours in the supply air duct run. The filter elements are not included with the filter housing and need to be purchased separately. The filter housing can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	306 mm
Width	536 mm
Depth	242.2 mm
Weight	6.66 kg

Side view



maintenance





Dimensions

Zehnder ComfoWell mounting plate CW-M 520

Article number: 990 323 615

Description

Mounting Plate: Zehnder ComfoWell mounting plate CW-M 520-10 x 90. Manifold mounting plate for connection of

10 x ComfoTube 90mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

Height	45mm
Width	536mm
Depth	230mm
Weight	<2.42 kg

Zehnder ComfoWell mounting plate CW-M 520

Article number: 990 323 614

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 520-10 x 75. Manifold mounting plate for connection of 10x ComfoTube 75mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

45mm
536mm
230mm
<2.42 kg



Front view

Top View

Top View











Zehnder ComfoWell end plate CW-P 520 -ø 150

Article number: 990 323 568

Description

End Plate:

Zehnder ComfoWell end plate CW-P 520 - DN150 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	536mm
Depth	230mm
Diameter	150mm



Zehnder ComfoWell end plate CW-P 520 -ø 160mm

Article number: 990 323 564

Description

End Plate:

Zehnder ComfoWell end plate CW-P 520 - DN160 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	536mm
Depth	230mm
Diameter	160mm

Side view

Front view



42.3-

Side view



42.3

Front view



Dimensions

Zehnder ComfoWell end plate CW-P 520 -ø 180mm

Article number: 990 323 513

Description

End Plate:

Zehnder ComfoWell end plate CW-P 520 - DN180 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	536mm
Depth	230mm
Diameter	180mm

Zehnder ComfoWell end plate CW-P 520 -ø 200mm

Article number: 990 323 514

Description

End Plate:

Zehnder ComfoWell end plate CW-P 520 - DN200 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	536mm
Depth	230mm
Diameter	200mm





Zehnder ComfoWell spacer frame, CW-DF 520

Article number: 990 323 539

Description

Zehnder ComfoWell spacer frame CW-DF520. Rectangular frame for use in the event of uneven surfaces when connecting components and mounting plate (concreted in place) are at 90 degrees. The spacer frame includes the necessary mounting accessories.

Side view





Top View



Height	27.8mm
Width	536mm
Depth	230mm
Weight	1.36 kg





Zehnder ComfoWell mounting set, CW-K 520, for Zehnder ComfoAir Q350

Article number: 990 323 649

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 520 for direct mounting to the ComfoAir Q350 ventilation units. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets).

Front view

Side view

Dimensions

Height	61.8mm
Width	536mm
Depth	510.5mm
Weight	4.56 kg

Top View Ø159.0

Dimensions

Zehnder ComfoWell mounting set, CW-K 520, for Zehnder ComfoAir Q450/600

Article number: 990 323 646

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 520 for direct mounting to the ComfoAir Q450/ComfoAir Q600 ventilation units. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets).

Dimensions

Height	61.8mm
Width	536mm
Depth	510.5mm
Weight	5.5 kg



Side view



Front view

Top View

Ø179.0



Pressure Curve

Comfowell 520



Sound Data

Comfowell 520

Combination	Octave Band (Hz) Insertion Loss, dB							
Combination	63	125	250	500	1000	2000	4000	8000
1 x Attenuator (CW-S 520) with 2 x 180mm end plates (CW-P 520)	2,0	6,3	10,3	16,5	12,0	20,4	15,0	13,5
2 x Attenuator (CW-S 520) stacked with 2 x 180mm end plates (CW-P 520)	6,7	12,3	20,3	22,5	19,2	37,8	27,6	23,9

For use with

Our range of Comfowell units can be used in conjunction with our Zehnder ComfoTube ø 75mm and ø 90mm semi-rigid ductwork.



BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by following the link below.





Consultant specification

Specification

The semi-rigid ductwork manifold shall be constructed of galvanised sheet steel with a closed-cell melamine resin foam inner lining to prevent dust collection and have a fire class C rating according to EN ISO13501.

It shall be of modular construction with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm.

It shall have the option of a mounting set for direct connection to the mechanical ventilation with heat recovery unit. The components shall be tested to BS EN 1507:2006 and BS EN 12237:2003 for airtightness and have removable elements to provide access for cleaning.





Zehnder ComfoPost CW12*



ComfoPost CW12

The Zehnder ComfoPost is an air to water exchanger for use with ComfoWell air distribution connections. The ComfoWell connections allows for selection flexibility, offering a range of rigid circular ductwork or Zehnder ComfoTube semi-rigid ductwork to attached. The ComfoPost is available in a variety of sizes to heat or cool the air supplied by the Zehnder ventilation system.

The ComfoPost units are suitable for a wide range of airflows up to 166I/s (600m³hr), the CW12 is suitable for airflows up to 166I/s (600m³hr). The units are made of steel with aluminium and copper pipe forming the heating and cooling coils and are maintenance free.

Key Features

- Ideal for use with reversible heat pumps or chillers to meet SAP 10 or TM59 overheating demands
- Low pressure losses
- Filtered fresh supply air, not recycled stale air
- Suitable for use with the unique modular ComfoWell manifolds
- Suitable for horizontal or vertical installation
- Condensation water tray and drain as standard
- Suitable for Passive House application
- Corrosion resistant

Article Numbers

Description

Product Code 399 000 003

Zehnder ComfoPost CW12 post-treatment battery for heating and cooling with an airflow up to 600m³/h

Technical Specification

Height	230mm
Width	625mm
Depth	520mm
Water connection diameter (ø)	1/2"
Water connection type	BSPT male thread
Condensate drain diameter OD (ø)	14mm
Condensate connection type	Worm drive clip to fix to hose or crimped to copper pipe
ComfoWell range	ComfoWell 625
ComfoWell rigid round air connection options (ø)	150mm / 160mm / 180mm / 200mm
ComfoWell semi-rigid air connection options (ø)	12 x 75mm / 12 x 90mm / 6 x 90mm + 6 x 75mm
Material	Casing: Galvanised sheet steel Tubes: Copper Fins: Aluminium with hydrophilic treatment
Recommended operating water temperature range	7 to 55 °C
Recommended maximum operating air flow	<166.6l/s (<600m ³ hr)
Maximum thermal heating output	6.51kW*
Maximum thermal cooling output	5.64kW*
Maximum operating water pressure	6 bar
Water volume capacity	1.2 Litres
Maintenance free	Yes
Weight	22.4 kg

*Total capacity (sensible and latent) based on test conditions shown in the Performance Data table

3D System Layout





Height	230mm
Width	625mm
Depth	520mm
Weight	22.4 kg







■ For use with Zehnder ComfoWell 625

Performance Data

			Heating				Cooling					
Air conditions IN to ComfoPost T °C			HRV exc	changer			ERV exc	changer		HRV	ERV	
		T °C	18 °C		17 °C			27°C	28°C			
		RH %		25	%			60	1%		80%	55%
		AH		3.2 (g/kg			7.3	g/kg		18.1 g/kg	13.1 g/kg
Wa	ter temperature IN	°C	55	50	45	40	55	50	45	40	7	7
	H ₂ O flow	l/h		60	00			60	00		600	600
	H ₂ O temperature _{OUT}	°C	49	45	41	36	49	45	40	36	13	12
մ ³ /h)	H ₂ Ο ΔΡ	kPa	15	15	16	16	15	15	16	16	19	19
4 360n	Air temperature OUT	°C	52	47	43	38	52	47	43	38	13	12
1001/s (3	Air RH _{OUT}	%	4	5	6	8	9	11	14	18	100	96
	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	9.5	8.1
_ vol	Air ΔP	Pa	8	8	8	7	8	8	8	7	15	11
Air1	Condensation	l/h	-	-	-	-	-	-	-	-	3.7	2.2
	Sensible power	kW	-	-	-	-	-	-	-	-	1.69	2.01
	TOTAL POWER	kW	4.14	3.57	3.01	2.45	4.27	3.71	3.14	2.58	4.31	3.52
	H ₂ O flow	l/h		60	00			60	00		600	600
-	H_2O temperature _{OUT}	°C	48	44	40	36	48	44	40	36	14	13
l/s (432m ³ /h)	$H_2O \Delta P$	kPa	15	16	16	16	15	16	16	16	19	19
	Air temperature _{OUT}	°C	51	47	42	38	51	46	42	37	14	12
	Air RH _{OUT}	%	4	5	6	38	9	11	14	18	100	95
120	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	10.2	8.5
flow	Air ΔP	Pa	10	9	9	9	10	9	9	9	18	14
Air	Condensation	l/h	-	-	-	-	-	-	-	-	4.1	2.4
	Sensible power	kW	-	-	-	-	-	-	-	-	1.92	2.29
	TOTAL POWER	kW	4.81	4.16	3.5	2.85	4.98	4.31	3.65	3	4.78	3.94
	H ₂ O flow	l/h		60	00			60	00		600	600
-	H ₂ O temperature _{OUT}	°C	47	43	39	35	47	43	39	35	14	13
m³/h	H ₂ O ΔP	kPa	15	16	16	16	15	15	16	16	19	19
(504	Air temperature OUT	°C	50	46	41	37	50	45	41	37	15	13
01/s	Air RH _{OUT}	%	4	5	7	8	10	12	15	19	100	93
v 14	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	10.8	8.9
flov	Air ∆P	Pa	12	11	11	11	12	11	11	11	22	16
Air	Condensation	l/h	-	-	-	-	-	-	-	-	4.4	2.6
	Sensible power	kW	-	-	-	-	-	-	-	-	2.07	2.55
	TOTAL POWER	kW	5.44	4.7	3.96	3.22	5.62	4.87	4.13	3.38	5.17	4.31
	H ₂ O flow	l/h		60	00			60	00		600	600
(ų	H ₂ O temperature _{OUT}	°C	46	42	38	35	46	42	38	34	15	14
ĨE O	H ₂ Ο ΔΡ	kPa	16	16	16	16	16	16	16	16	19	19
м (60	Air temperature _{OUT}	°C	48	44	40	36	48	44	40	36	16	14
XIMI 61/s	Air RH _{OUT}	%	5	6	7	9	10	13	16	20	99	92
MA. 166	Air AH _{OUT}	g/kg	3.2	3.2	3.2	3.2	7.2	7.2	7.2	7.2	11.3	9.3
flow	Air ΔP	Pa	15	15	15	15	15	15	15	15	29	20
Air	Condensation	l/h	-	-	-	-	-	-	-	-	4.8	2.7
	Sensible power	kW	-	-	-	-	-	-	-	-	2.26	2.84
	TOTAL POWER	kW	6.3	5.44	4.59	3.73	6.51	5.64	4.78	3.92	5.64	4.73

Initial temperature and humidity outdoor/indoor: winter 2°C 70% R.H. / 20°C 60% R.H.; summer 35°C 50% R.H. / 25°C 50% R.H. The calculations include the cold recovery efficiency of an enthalpy exchanger as extrapolated from the results provided by the PHI certification

Performance Data



	3 Zi Ci 990 323 639 Zehnder ai	99 DDO D ehnder omfoPost ost-tred attery f eating ai ooling wi
Exploded view	ComfoWell end 6 plate, CW-P 625, ø 200mm	00m3∕h ́
		ħ° .

Front view

Top view

Example Connection



Schematics



■ For use with Zehnder ComfoWell 625



For Use With

Our range of ComfoPost products can be used in conjunction with our ComfoAir units, complete with enthalpy cube for improved sensible cooling capacity. The unit shall be manufactured by Zehnder.



BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY

CLICK HERE

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

TO VISIT OUR DOWNLOAD PAGE



Consultant specification

Specification

The air to water exchanger shall be constructed of galvanised sheet steel with copper tubes and aluminum fins with hydrophilic treatment to enhance thermal transfer. It shall be connected to the MVHR units supply ductwork with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm. It shall have the option for horizontal or vertical mounting.

The unit shall be manufactured by Zehnder.





Comfowell 625

The Zehnder ComfoWell 625 is a modular system consisting of attenuators, fine grade filters and active carbon filters all integrated for use with a rigid or semi-rigid ductwork approach. With a width of 625mm it can be used for connecting up to 12 ComfoTube connections. The system's compact dimensions ensure good sound absorption and also make it easy to clean. Rigid pipe can be connected to the end plate securely by utilising the gasket seal connection. All other components are fitted using the locking slide connections to form an airtight and robust seal.

Noise reduction can be improved by combining two attenuators together. Filters are available in ISO ePM1 >80% (F7) or ISO ePM1 >90% (F9) grade in addition to an odour neutralising active carbon filter.



Key Features

- Attenuator, fine grade filter, active carbon filter and manifold all combin build exactly what is required.
- Easy to assemble thanks to its modular and compact design.

Article Numbers

Description

Attenuator

Zehnder ComfoWell attenuator, CW-S 625

Manifold

Zehnder ComfoWell manifold box CW-D 625

Filter Housing

Zehnder ComfoWell filter housing CW-F 625

Mounting Plates

Zehnder ComfoWell mounting plate, CW-M 625, 12 x 75mm connections Zehnder ComfoWell mounting plate, CW-M 625, 12 x 90mm connections

End Plates

Zehnder ComfoWell end plate, CW-P 625, ø 150mm
Zehnder ComfoWell end plate, CW-P 625, ø 160mm
Zehnder ComfoWell end plate, CW-P 625, ø 180mm
Zehnder ComfoWell end plate, CW-P 625, ø 200mm

Zehnder ComfoWell 625





• Attenuator, fine grade filter, active carbon filter and manifold all combined into one space saving combination with the option to bespoke

Product Code

990 323 505
990 323 630
990 323 555
990 323 631
990 323 632
990 323 636
990 323 637
990 323 638
990 323 639

Example Connections

Combination Options	ComfoAir Q600 right handed with mounting set, 2 x attenuators and 2 x 12 port ø 90mm mounting plates	Stand alone attenuator with 2 x ø 200mm end plates	Stand alone with 1 x ø 20 plate and 12 mountin
Individual Components			888
Attenuator	2 x Zehnder ComfoWell attenuator, CW-S 625	1 x Zehnder ComfoWell attenuator, CW-S 625	
Manifold Box			1 x Zehnder (manifold bo 625
Filter Housing			
Mounting Plate -ø90	2 x Zehnder ComfoWell mounting plate, CW-M 625, 12 x 90mm connections		1 x Zehnder mounting CW-M 62 90mm con
End Plate - ø 200		2 x Zehnder ComfoWell end plate, CW-P 625, ø 200mm	1 x Zehnder end plate, (ø 200
Mounting Set	1 x Zehnder ComfoWell mounting set, CW-K 625, for Zehnder ComfoAir Q450/600		
Filter			

Article Numbers

Spacer Frame	
Zehnder ComfoWell spacer frame, CW-DF 625	990 323 634
Mounting Set	
Zehnder ComfoWell mounting set, CW-K 625, for Zehnder ComfoAir Q450/600	990 323 642
Filters	
Filter for ComfoWell 625, CW-F7 625, ISO ePM1 >80% (F7), 1 Piece	990 323 653
Filter for ComfoWell 625, CW-F9 625, ISO ePM1 >90% (F9), 1 Piece	990 323 654
Filter for ComfoWell 625, CW-AC 625, active carbon filter, 1 Piece	990 323 655

Technical Specification

Housing material	Galvanised sheet steel
Operating temperature range	-25 to +60 °C
Inner lining	Closed-cell melamine resin foam
Recommended maximum air volume	133.3l/s (480 m ³ /h) at normal ventilation level
Air tightness class to EN 1507:2006	С
Air tightness class to EN 12237:2003	С
Fire rating to ISO13501	С

lone manifold ø 200mm end d f2 x e 90mm nting plate	Stand alone filter housing with 2 x ø 200mm	Stand alone silencer and manifold combined with 1 x o 200mm end plate and 12 x o 90mm mounting plate	Stand alone 2 x attenuator with 1 x ø 200m end plate and 12 x ø 90mm mounting plate
		1 x Zehnder ComfoWell attenuator, CW-S 625	2 x Zehnder ComfoWell attenuator, CW-S 625
er ComfoWell I box, CW-D 625			
	1 x Zehnder ComfoWell filter housing, CW-F 625		
der ComfoWell Iting plate, // 625, 12 x connections		1 x Zehnder ComfoWell mounting plate, CW-M 625, 12 x 90mm connections	1 x Zehnder ComfoWell mounting plate, CW-M 625, 12 x 90mm connections
der ComfoWell e, CW-P 625, 200mm	2 x Zehnder ComfoWell end plate, CW-P 625, ø 200mm	1 x Zehnder ComfoWell end plate, CW-P 625, ø 200mm	1 x Zehnder ComfoWell end plate, CW-P 625, ο 200mm
	1 x Filter for ComfoWell 625, CW-F9 625, ISO ePM1 >90% (F9), 1 Piece		

Zehnder ComfoWell attenuator, CW-S 625

Article number: 990 323 505

Description

Attenuator:

Zehnder ComfoWell attenuator CW-S 625. Rectangular compact attenuator with highly efficient sound insulation combined with low pressure losses. The attenuator can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

For cleaning purposes the sound absorbing element can be removed. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	506mm	
Width	625mm	
Depth	233.8mm	
Weight	8 kg	

Top View

Zehnder ComfoWell manifold box CW-D 625

Article number: 990 323 630

Description

Manifold Box:

Zehnder ComfoWell manifold box CW-D 625. Rectangular compact design with closed pore internal lining. Suitable for use with the mounting plate for ComfoTube 75mm x 12 connections, 90mm x 12 connections or a combination of 90mm x 6 and 75mm x 6 connections. The mounting plate can be mounted on the top or side of the manifold box. The airtight connection between components is via a clamping strip.

For cleaning purposes the manifold box side plate can be removed for easy access. Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	233mm
Width	641mm
Depth	259 mm
Weight	6.5 kg

Top View

Side view

Front view



Dimensions

Zehnder ComfoWell filter housing CW-F 625

Article number: 990 323 555

Description

Filter Housing:

Zehnder ComfoWell filter housing CW-F 625. Rectangular compact design for use with a fine pollen filter graded ISO ePM1 >80% (F7), a fine dust filter graded ISO ePM1 >90% (F9) or an active carbon filter to neutralise odours in the supply air duct run. The filter elements are not included with the filter housing and need to be purchased separately. The filter housing can be used individually or in combination with all ComfoWell components. The airtight connection between components is via a clamping strip.

Mounting on the wall or ceiling is done using the supplied fully adjustable installation mounts.

Dimensions

Height	306 mm
Width	627.5 mm
Depth	242.2 mm
Weight	1.68 kg

Zehnder ComfoWell mounting plate CW-M 625

Article number: 990 323 631

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 625-12 x 75. Manifold mounting plate for connection of 12x ComfoTube 75mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.

Dimensions

Height	45mm
Width	641mm
Depth	230mm
Weight	<2.2 kg



Front view

Side view





Access for

aintenance

ccess for

aintenance



Zehnder ComfoWell mounting plate CW-M 625

Article number: 990 323 632

Description

Mounting Plate:

Zehnder ComfoWell mounting plate CW-M 625-12 x 90. Manifold mounting plate for connection of 12 x ComfoTube 90mm semi-rigid ducting.

The mounting plate includes a protective film and the necessary mounting accessories.



45.0

Front view

Side view



Dimensions

Height	45mm
Width	641mm
Depth	230mm
Weight	<2.2 kg





Dimensions

Zehnder ComfoWell end plate CW-P 625 -ø 150

Article number: 990 323 636

Description

End Plate:

Zehnder ComfoWell end plate CW-P 625 - DN150 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	641mm
Depth	230mm
Diameter	150mm

Zehnder ComfoWell end plate CW-P 625 -ø 160mm

Article number: 990 323 637

Description

End Plate:

Zehnder ComfoWell end plate CW-P 625 - DN160 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	641mm
Depth	230mm
Diameter	160mm



Zehnder ComfoWell end plate CW-P 625 -ø 180mm

Article number: 990 323 638

Description End Plate:

Zehnder ComfoWell end plate CW-P 625 - DN180 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.



Side view



Front view



Dimensions

Height	42.3mm
Width	641mm
Depth	230mm
Diameter	180mm

Ø179.0 Top View



Zehnder ComfoWell end plate CW-P 625 -ø 200mm

Article number: 990 323 639

Description

End Plate:

Zehnder ComfoWell end plate CW-P 625 - DN200 (with centre connection) for the connection to the ComfoWell attenuator/manifold box or filter housing to the matching ducting size required. The end plate includes the necessary mounting accessories.

Dimensions

Height	42.3mm
Width	641mm
Depth	230mm
Diameter	200mm





Side view



42.3

Front view



Dimensions

Zehnder ComfoWell spacer frame, CW-DF 625

Article number: 990 323 634

Description

Zehnder ComfoWell spacer frame CW-DF625. Rectangular frame for use in the event of uneven surfaces when connecting components and mounting plate (concreted in place) are at 90 degrees. The spacer frame includes the necessary mounting accessories.

Dimensions

Height	27.8mm
Width	641mm
Depth	230mm
Weight	1.36 kg

Zehnder ComfoWell mounting set, CW-K 625, for Zehnder ComfoAir 450/600

Article number: 990 323 642

Description

Mounting set:

A special mounting set is available for the Zehnder ComfoWell 625 for direct mounting to the ComfoAir Q450/600 ventilation units. The mounting set includes all the necessary accessories (screws, brackets and mounting brackets).

Dimensions	
Height	61.8mm
Width	641mm
Depth	510.5mm
Weight	5.17 kg





Pressure Curve





1 x Filter housing (CW-F 625) with 2 x 180mm end plates (CW-P 625) and filter (CW-F9 625)

For use with

Our range of Comfowell units can be used in conjunction with our Zehnder ComfoTube ø 75mm and ø 90mm semi-rigid ductwork.



BIM/CAD Components

If you would like to download the BIM / CAD files for this or any other of our products then please visit our BIM library.

TO VISIT OUR BIM/CAD LIBRARY

Installation Instructions

If you would like to download the installation files for this or any other of our products then please visit our download page by clicking the link below.

Sound Data Comfowell 625

Combination	Octave Band (Hz) Insertion Loss, dB							
	63	125	250	500	1000	2000	4000	8000
1 x Attenuator (CW-S 625) with 2 x 180mm end plates (CW-P 625)	3,0	8,9	13,7	18,7	12,0	18,6	14,6	12,9
2 x Attenuator (CW-S 625) stacked with 2 x 180mm end plates (CW-P 625)	9,2	17,0	23,4	23,8	21,0	34,2	26,4	22,6







Consultant specification

Specification

The semi-rigid ductwork manifold shall be constructed of galvanised sheet steel with a closed-cell melamine resin foam inner lining to prevent dust collection and have a fire class C rating according to EN ISO13501.

It shall be of modular construction with options to combine attenuators, manifold box, filter housing with ISO ePM1 >80% (F7), ISO ePM1 >90% (F9) or active carbon filters and end plates ranging from ø 125mm to ø 200mm.

It shall have the option of a mounting set for direct connection to the mechanical ventilation with heat recovery unit. The components shall be tested to BS EN 1507:2006 and BS EN 12237:2003 for airtightness and have removable elements to provide access for cleaning.

